



NOTE:
 ● = COLUMN
 ▼ = PULL BOXES
 ▲ = FIRE EXTINGUISHERS
 * = FIRE HOSE CABINETS & F.D.C.
 ⊕ = FIRE DEPT. CONNECTIONS
 □ = UTILITIES - FLOOR BOX
 W & D = WATER & DRAIN @ FLOOR BOX
 480 = 480 ELEC. SVC. @ FLOOR BOX
 AIR = AIR SVC. @ FLOOR BOX
 ALL FLOOR BOXES HAVE 120/208 ELEC. SVC.
 ALL SINGLE COLUMNS HAVE 2 FIRE EXT.
 ALL DOUBLE COLUMNS HAVE 1 FIRE EXT. PER COLUMN

Tampa Convention Center

1/16" = 1'-0"

Scale
 0' 5' 10' 15' 20'